
#### STYLEX Model: F4

## Disassembly and Recycling Document Disassembly Time: 10 min / No Special Training Required

#### **Tools Required**

Safety Glasses 5/32 Allen Wrench 3/16 Allen Wrench 5/64 Allen Wrench #2 Phillips Screwdriver Mallet







### Breakdown Steps

1. Flip the chair over and remove the 8 screws holding the seat in place. Slide the seat forward and pull up to remove the seat. (Figure A1)



- Seat Back

 Material: Glass Filled Nylon, Mesh Upholstery



- Socket Head Shoulder Screw

- Material: Steel



2. Unscrew the 2 screws at the botton of the back and pull the seat back up to remove. (Figure B1)



- Seat

- Material: Polypropolyne, foam





- Carriage

- Material: Aluminum





- Socket Head Shoulder Screw

- Material: Steel



- Spring

- Material: Steel



3. Unscrew 2 screws per arm to remove the arm pads. (Figure C1)





# Disassembly and Recycling Document Disassembly Time: 10 min / No Special Training Required

4. Flip the chair over and remove the casters from the base. (Figure D1)



-Cylinder - Material: Aluminum, Steel - 5 Blade Base - Material: Aluminum - Casters - Material: Steel, Nylon