

STYLEX

Model: Ridge Guest w/ cantilever base

*Refer to P.2 for model variations

Disassembly and Recycling Document

Disassembly Time: 10min / No Special Training Required


Tools Required

safety glasses
phillips screwdriver



Breakdown Steps

1. Turn the chair upside down to reveal the screw holding the metal frame to the wooden seat. Start by using a phillips head screw driver to remove the screws (figure A1).



3. After the base is removed use the same tool to remove the screws holding the seat to the metal L brackets (figure B1).



3. Remove the seat from the back of the chair (figure C1).



4. Finally remove the screws that are holding the L brackets to the back of the chair (figure D1).



- Seat Back
- Material:
Foam, upholstery



- Upholstered Seat
- Material:
Foam, plywood, upholstery



- Cantilever frame
-Material: Aluminum ♻️



- L Bracket x5
-Material: Steel ♻️



- Phillips truss-head (1/4 20 screw) x10
-Material: Steel ♻️



Chair Variations

All Ridge Guest chairs are fully upholstered and have a broad array of base options.

- Aluminum 4 blade base (Figure A1)
- 4 wooden legs (Figure A2)
- Steel sled frame (Figure A3)
- Steel cantilever frame (Figure A4)
- Aluminum five star base (Figure A5)

♻️ All metal bases can be recycled

Disassembly for all of these versions is fairly similar to the model on P1. Please reference instructions on P1 to disassemble any of these models.

Figures A1, A2, A3, and A4 all have removable leg glides that can be pried off or unscrewed. Figure A5 has wheel casters which can be pulled from the frame by hand.

A1



A2



A3



A4



A5

