

# STYLEX

Model: Verve with 4 Blade base


\*Refer to P.2 for model variations

## Disassembly and Recycling Document

Disassembly Time: 5min / No Special Training Required


### Tools Required

- safety glasses
- 5/32 allen wrench




### Breakdown Steps


1. Turn the chair on its back to reveal the aluminum 4 blade swivel base. Start by using a 5/32 allen key to remove the 1/4-20 Shoulder head cap screw. When the screw is removed pull up the base to separate it from the spigot (figure A1).




2. After removing the base from the chair, use the same allen key to unscrew the screws holding the aluminum carriage onto the shell. (figure B1).




3. Finally, separate the arms and spigot from the carriage using the 5/32 allen key (figure C1).



- Seat Shell
- Material: Polypropylene, foam upholstery



- Carriage
- Material: aluminum, steel



- Phillips button-head (1/4 20 bolt)
- Material: Steel

x4



- Washers
- Material: Steel

x4



- 4 Blade Base
- Material: Aluminum



- Socked Head shoulder Screw
- Material: Steel
- Washer
- Material: Steel

x1



- Casters
- Material: Steel, Nylon

x4



**STYLEX**

Model: Verve

**Disassembly and Recycling Document**  
Disassembly Time: 5min / No Special Training Required

## Chair Variations

## Verve

All Verve chairs have various options for upholstery and base options:

- Fully upholstered liner with 4 blade base (figure A1).
- Fully upholstered with 5 blade base (figure A2).
- Shell with seat and sled frame (figure A3).

Disassembly for all of these versions is fairly similar to the original. Please use P1 as a disassembly reference for all of these variations.

♻️ All bases can be recycled

A1



A2



A3

