## **STYLEX**

## Disassembly and Recycling Document Model: Obair Table

Refer to Stylex website for model variations

## **Tools Required**

Safety glasses 1/4" Hex Key 5/32" Hex Key



## Breakdown Steps

- 1.Flip table upside down and remove glides. (Figure A1)
- 2. Using the 1/4" hex key, remove the first 3 bolts from base assembly (Figure B1) in order to remove the counterweight subassembly.
- 3. Remove the 6 mounting screws from shroud and counterweight using the the 5/32" Hex key. (Figure C1).
- 4. Separate the top mounting plate column assembly from the top by removing the 6 mounting screws using a 5/32" hex key.
- 5A. Using a 1/4" hex key, remove the 3 screws connecting the top mounting plate to the column. (Figure D1).
- 5B. If the table is rectangular, you will need the 3/8" wrench as specified in the assembly instructions to take off the stretcher after removal of columns.



