# STYLEX

**Model: Metrum one seater** \*Refer to P.2 for model variations

#### **Tools Required**

safety glasses phillips screwdriver 3/8 wrench with extension 7/16 wrench (for arms)



## **Breakdown Steps**

 Turn the chair on its side (or back if a large unit) to reveal the metal legs. Locate the 4 legs.

- Using a phillips head screw driver or drill, remove all screws from the frame, releasing the legs from the seat wood (figure B1).
- To remove the back frame from the seat, locate the hex bolts towards the back of the seat. Using a 3/8 wrench, uncrew each of the bolts.

4. Finally, release the back from the seat.









- Back cushion - Material: Foam, plywood, upholstery

**Disassembly and Recycling Document** 

Disassembly Time: 10min / No Special Training Required



- Seat cushion - Material:

Foam, plywood, upholstery



Wood Leg optional



-Phillips round head (1/4 20) Material: Steel x4**3** 

-Washer x6Per seat -Hex Washer Bolt x6Per seat (1/4 20) Material: Steel



111111111111

STYLEX Model: Metrum

## **Disassembly and Recycling Document**

Disassembly Time: 10min / No Special Training Required

### **Chair Variations**

Dissesembly for other Metrum units is similar to the single seater disassembly on P1. Refer to P1 for instructions.

1 Seater 2 Seater Settee 3 Seater Corner Chaise High Back 1 Seater High Back 2 Seater High Back 3 Seater High Back 1 Corner



#### Arm Removal

Standard, bookshelf, cantilever, privacy, mid-arm. All arms are bolted to the frame using either a hex bolt or threaded studs welded to the arm and held down with a nut. The following example is using hex bolts.

- Turn the chair on its back to have better access to the hex bolts holding the arm to the chair frame.
- 3. There are 3 bolts holding the arm to the seat (figure A1, B1) and 2 bolts holding the arm to the back. (figure B2).

3. After locating the bolts, use a 3/8 wrench to remove them. For cantilever arm or mid arms, use a 7/16 wrench to remove the nut. (Note: Mid-arm is removed the same way you would a normal arm, except it is not attached to the back, only the seat.)

www.stylexseating.com









800.257.5742

